

| ILLUSTRATION   | DESCRIPTION  | PACKING        | € per pack.  | Discounts Q.ty %        | CODE                           |       |
|--|--|----------------|--|-------------------------|--------------------------------|-------|
|  | <b>"Spring Lock" security hanging system</b><br><b>Kit A</b> includes: <ul style="list-style-type: none"> <li>• A couple of bridges</li> <li>• A couple of locks</li> <li>• Four screws to fix the bridges to the frame</li> </ul> To install the SpringLock system to the frame to have to follow these steps:<br>1) Fit the two bridges to the frame using the screws.<br>2) On the wall fit two screws in corresponding positions.<br>The kit does not include these screws (for screw see page 33).<br>3) Frame is offered up and the bridges fitted over the screws in the wall.<br>4) Locks are pushed home with thumb pressure. |                | Kit for 1 frame  | 2,60                    | 10%<br>20%<br>30%              | SL    |
|  |  |                | Kit for 25 frames  | 38,00                   | 5%<br>10%<br>15%               | SLF   |
|  |  |                | Kit for 100 frames   | 140,00                  |                                | SLC   |
|  | <b>Kit B</b> is to be used when hanging frames closely side by side. It includes: <ul style="list-style-type: none"> <li>• A couple of Hang Plates to fit at the top of the frame</li> <li>• One bridge to fit on the bottom of the frame.</li> <li>• Six screws</li> <li>• One SpringLock</li> </ul> The steps to follow for the kit B are similar to the steps for the kit A.  |                | Kit for 1 frame  | 2,20                    | 4%<br>10%<br>20%<br>25%<br>30% | 3943  |
|  | <b>Kit C</b> Self-adhesive plate system with SpringLock<br>The kit includes: 2 self-adhesive plates, 2 SpringLock<br>Instructions: 1) Fit the 2 self-adhesive plates on the frame 2) On the wall fit the 2 screws in corresponding position 3) Fit the frame on the wall so that the screw head enters into the plate 4) Apply the SpringLock by pushing it with your hand.<br>To unlock the frame you need the special tool SL1. Maximum frame weight 4 Kg.   |                |  | 3,50                    | 5%<br>10%                      | 9486  |
| <b>Kit D</b> Self-adhesive plate system with "T"-screws<br>The kit includes: 2 self-adhesive plates, 2 "T"-screws, 2 wall plugs for screws<br>Instructions: 1) Fit the 2 self-adhesive plates on the frame 2) On the wall fit the 2 screws in corresponding position 3) Fit the frame on the wall so that the screw head enters into the plate 4) With the special tool (AS9) turn the head of the screw.<br>To unlock the frame you need the special tool AS9. Maximum frame weight 4 Kg. |  |                | 3,20   | 5%<br>10%               | 9523                           |       |
| Single items can be ordered apart :  |  |                |  |                         |                                |       |
|  | Bridges for the kit A with springs and screws  | 50 pieces      | 38,00  | 5%<br>10%               | 4647                           |       |
|  | Plates for security hangers for the kit B with screws  | 10 pieces      | 4,80   | 5%<br>10%               | 4648T                          |       |
|  |  | 50 pieces      | 21,00  | 5%<br>10%               | 4648                           |       |
| To remove the frame you need the release tool that is available in two versions:   |  |                |  |                         |                                |       |
|  | SL1<br>• Release tool with hanging hole  |                | 3,40   | 4%<br>10%<br>15%<br>20% | SL1                            |       |
|  | 5693<br>• Marker Button.<br>Fits into bridge to mark wall for screw.   |                | 1,40   | 4%<br>10%<br>15%        | 5693                           |       |
|  | 7165<br>• Release tool with integral marker to mark wall screw.  |                | 5,10   | 4%<br>10%<br>15%        | 7165                           |       |
|  | <b>Security Hanging System "AS"</b> . It works as follows:<br>1) Apply 2 horizontal grooved metal plates onto the top of the frame.<br>A third one is placed along the bottom back of the frame.<br>2) Insert 3 special T-screws into the wall at the same distance of the plates.<br>3) The frame with the 3 metal plates is fitted over the screws.<br>4) Tighten the screws by using the special spanner (AS9) until they are vertically positioned. Now the frame is firmly secured and the frame can be removed only by the spanner.  |                | Kit for 1 frame:<br>- 3 plates<br>- 6 screws to fix the plates<br>- 3 T-screws and wall plugs  | 3,00                    | 5%<br>10%                      | AS    |
|  |  |                | Kit for 10 frames:<br>- 30 plates<br>- 60 screws to fix the plates<br>- 30 T-screws with wall plug   | 12,00                   | 5%<br>10%                      | AS10  |
|  | <b>Security Hanging System "ASW"</b> .<br>It uses 2 brackets (code AS3) instead of 2 T-screws.<br>The rest of the procedure is the same as described above.  |                | Kit for 1 frame:<br>- 3 plates<br>- 6 screws to fix the plates<br>- 2 brackets<br>- 2 screws with wall plugs<br>- 1 T-screw with wall plug | 2,60                    | 5%<br>10%<br>15%               | ASW   |
|  | Special spanner for T-screws (has to be ordered apart)   | 1 piece        | 1,80   | 5%<br>20%               | AS9                            |       |
| Single items can be ordered apart:   | Plates to be fixed to the back of frames   | pack 100 pces  | 10,00  | 3%<br>8%                | AS1C                           |       |
|  |  | pack 1000 pces | 90,00  | 3%<br>8%                | AS1                            |       |
|  | Screws for fixing the plates to frames. Length 13 mm. Diameter 2,9 mm  | pack 100 pces  | 3,10   | 3%<br>8%<br>15%         | AS8C                           |       |
|  | Brackets   | pack 100 pces  | 9,30   | 3%<br>8%                | AS3C                           |       |
|  |  | pack 1000 pces | 112,00   | 3%<br>8%                | AS3                            |       |
|  | T-screws. Length 39 mm. Diameter 6 mm.   | pack 100 pces  | 17,50  | 3%<br>8%                | AS4C                           |       |
|  |  | pack 1000 pces | 132,00   | 3%<br>8%                | AS4                            |       |
| Wall plugs for screws  | for brackets screws (diam. 6)  | pack 100 pces  | 3,20   | 3%<br>8%                | AS7C                           |       |
|  | for T-screws (diam. 8)   | pack 100 pces  | 2,50   | 3%<br>8%                | AS5C                           |       |
| Screws for fixing brackets. Length 38 mm. Diameter 3.3 mm.   |  | pack 100 pces  | 4,90   | 3%<br>8%                | AS6C                           |       |
|  | <b>Safety hook</b> . Its function is to make it difficult to detach the frame from the hook.<br>The secret to removing the frame is to properly tilt the picture.<br>It bears a maximum weight of about 15 Kg.<br>The screw and the plug must be ordered separately.   |                | pack 20 hooks  | 10,00                   | 5%<br>10%                      | 9487V |
|  |  |                | pack 100 hooks   | 46,00                   | 5%<br>10%                      | 9487B |
|  | Screw and plug to fix the safety hook (code 9487B) to the wall.  |                | pack 100 screws + 100 wall plugs   | 7,50                    | 5%<br>10%                      | 9559  |
|  | Pack of 20 safety hooks plus the screw and the relative plug to fix the hook to the wall.  |                | pack 20 hooks + 20 screws + 20 plugs   | 12,50                   | 5%<br>10%                      | 9487A |